TABLE OF CONTENTS

Index

For vehicles with a navigation system, refer to the "Navigation System Owner's Manual" for information regarding the equipment listed below.

| Navigation systemAir conditioningWindshield wiper de-icerRear view monitor system | | Audio/video system Rear window and outside rear view mirror defogging Climate control | | |
|--|--|---|--|--|
| 1 | Before driving | 1-4. | Adjustable components (seats, mirrors, steering wheel) | |
| | | | Front seats | |
| 1-1. | Hybrid system | | Rear seats 82 | |
| | Hybrid system features28 | | Driving position memory84 | |
| | Hybrid system precautions 33 | | Head restraints 87 | |
| | Energy monitor/consumption | | Seat belts 90 | |
| | screen39 | | Steering wheel98 | |
| | Hybrid vehicle driving tips 45 | | Inside rear view mirror99 | |
| | | | Outside rear view mirrors 101 | |
| 1-2. | Key information | | | |
| | Keys 47 | 1-5. | Opening and closing the windows and moon roof | |
| 1-3. | Opening, closing and locking the | | Power windows 104 | |
| | doors | | Moon roof 107 | |
| | Smart access system with push-button start | 1-6. | Refueling | |
| | Wireless remote control 65 | | Opening the fuel tank cap 111 | |
| | Side doors 70 | | Operang the fact talk cap | |
| | Back door 74 | | | |

| 1-7. | Theft deterrent system Immobilizer system115 | 2 | When driving | |
|------|--|------|---|---|
| | Alarm | 2-1. | Driving procedures Driving the vehicle | 1 |
| 1-8. | Safety information Correct driving posture | | Power (ignition) switch | 2 |
| | classification system | 2-2. | Horn | 3 |
| | | | Gauges and meters | 4 |
| | | 2-3. | Operating the lights and windshield wipers Headlight switch | 5 |
| | | | Fog light switch | 6 |
| | | | washer | 7 |
| | | | | |

TABLE OF CONTENTS Index

| 2-4. | Using other driving systems | | |
|------|------------------------------|------|--|
| | Cruise control | 3 | Interior features |
| | Dynamic radar cruise control | 3-1. | Using the air conditioning system and defogger |
| | Rear view monitor system | | Automatic air conditioning system |
| 2-5. | Driving information | | Windshield wiper de-icer 302 |
| | Cargo and luggage | 3-2 | Audio system types |
| | | | audio switches |

| 3-3. | Using the Bluetooth® audio | 3-5. | Using the interior lights Interior lights list | |
|------|---|------|--|---|
| | Bluetooth [®] audio system | | Personal/interior light main switch | 1 |
| | Setting up a Bluetooth [®] enabled portable player 387 Bluetooth [®] audio system | 3-6. | Using the storage features List of storage features | 2 |
| 3-4. | Using the hands-free phone system (for cellular phones) | | Console box | 3 |
| | Hands-free system for cellular phones | 3-7. | Other interior features Sun visors | 4 |
| | (for cellular phones) | | Vanity mirrors | 5 |
| | Using the phone book 427 | | Seat heaters | 6 |
| | | | Garage door opener | 7 |
| | | | | |

| 4 | Maintenance and | care |
|---|-----------------|------|
| | | |

| 4-1. | Maintenance and care | |
|------|--|-----|
| | Cleaning and protecting the vehicle exterior | 490 |
| | Cleaning and protecting the | 405 |
| | vehicle interior | 495 |
| 4-2. | Maintenance | |
| | $Main tenance\ requirements$ | 498 |
| | General maintenance | 501 |
| | Emission inspection and maintenance (I/M) | |
| | programs | 505 |
| 4-3. | Do-it-yourself maintenance | |
| | Do-it-yourself service precautions | 506 |
| | Hood | 511 |
| | Positioning a floor jack | 513 |
| | Engine compartment | 515 |
| | 12-volt battery | 528 |
| | Tires | 535 |
| | Tire inflation pressure | 547 |
| | Wheels | 551 |
| | Air conditioning filter | 554 |
| | Electronic key battery | 556 |
| | Checking and replacing | |
| | fuses | |
| | Light bulbs | 5/1 |

5 When trouble arises

5-1. Essential information

| | Emergency flashers | 588 |
|------|--|-------|
| | If your vehicle needs to be towed | 589 |
| | If you think something is wrong | 595 |
| 5-2. | Steps to take in an emergency | y |
| | If a warning light turns on or a warning buzzer sounds | 596 |
| | If a warning message is displayed | 609 |
| | If you have a flat tire | 631 |
| | If the hybrid system will not start | 645 |
| | If you lose your keys | 647 |
| | If the electronic key does not operate properly | 648 |
| | If the 12-volt battery is discharged | . 651 |
| | If your vehicle overheats | 656 |
| | If the vehicle becomes stuck | 661 |
| | If your vehicle has to be stopped in an emergency | 663 |
| | | |

| Maintenance data (fuel, oil level, etc.) | | | |
|---|-----------------------------|--------------------|-------|
| Maintenance data (fuel, oil level, etc.) | 6 Vehicle specifications | Index | |
| Maintenance data (fuel, oil level, etc.) 666 Fuel information 681 Tire information 685 6-2. Customization 701 Customizable features 701 6-3. Initialization 1tems to initialize Items to initialize 722 7 For owners 724 Seat belt instructions for Canadian owners (in French) 725 SRS airbag instructions for Canadian owners (in French) 727 | 6-1. Specifications | Abbreviation list | 738 |
| Fuel information | ` ' | | |
| Tire information | · | Alphabetical index | 740 |
| 6-2. Customization Customizable features | | NA/1 1 | 750 |
| Customizable features | lire information 685 | What to do it | /52 2 |
| 6-3. Initialization Items to initialize | 6-2. Customization | | |
| Items to initialize | Customizable features 701 | | |
| Reporting safety defects for U.S. owners | 6-3. Initialization | | 3 |
| Reporting safety defects for U.S. owners | Items to initialize | | |
| Reporting safety defects for U.S. owners | | | 1 |
| U.S. owners | 7 For owners | | 4 |
| Seat belt instructions for Canadian owners (in French) | | | _ |
| Canadian owners (in French) | | | 5 |
| (in French) | | | |
| Canadian owners (in French)727 | | | |
| (in French) | SRS airbag instructions for | | 6 |
| | | | |
| 7 | (in French) | | |
| | | | 7 |
| | | | / |
| | | | |
| | | | |